




VISION MODES


You have the option to customize each channel to one of four vision modes.





From the live view, left-click on the channel you wish to change > Select Advance 





Enter the vision mode settings by pressing OK. 



Using the navigation arrows, select Day/Night, then OK. 



Select your preferred vision mode using the left and right navigation arrows > navigate down to return > select OK. 



Navigate down to Save & Exit and select OK. 

- Repeat for each channel by navigating to the next channel.
- Right click to view the main menu
- Double left click to return to your set camera view layout.

DOUBLE LED - The camera will record in full color during the day and black and white at night until motion is detected. When motion is detected, the spotlight will turn on for up to 60 seconds or as long as motion is detected, enabling color night recording during that duration.

Please note: "Spotlight" linkage must be enabled in motion detection. See Setting Up Event Notifications to enable.

IR - The camera will record full color during the day and black and white at night.

FULL COLOR - The camera will always record in color. At night, the spotlight will remain on to enable full color recording.

CLOSE - The camera will record in color during the day. At night, the camera's recording color will be dependent on ambient lighting.